


PRAYER STATION TENT


INSTALLATION INSTRUCTIONS

INSTRUCTIONS


1. Place the tent frame upright in the desired location. Carefully pull the outer frame legs partially open with another person assisting on the opposite side.




2. Place the canopy over the partially open frame, align the four corners and connect the velcro at each corner. Lift the frame up by the lower part of the truss until the frame is almost fully open.



3. Lock the slider bracket into place by holding the frame with one hand and lifting the slider bracket up into place until it securely locks.



4. Lift each leg and slowly pull down the inner leg until the leg pops into place. Repeat with each leg and adjust height of the Prayer Station Tent by using the push pin.



WARNING

PLEASE READ INSTRUCTIONS COMPLETELY BEFORE USING YOUR PRAYER STATION TENT!

Please use caution during setup and installation. If you have questions regarding installation and/or setup, please contact us:


PRAYER STATIONS: (888) 686-5550

IMPORTANT NOTES


1. Always use tie-downs, stakes and/or weight bags to secure your PRAYER STATION tent.
2. DO NOT set-up or leave your PRAYER STATION tent setup in hail, sleet, snow, lightning, strong winds or any harsh weather conditions.
3. It is recommended to remove canopy top from the frame after take down. Storing top on frame may result in excessive wear and tear that is not covered under warranty.
4. Use a diluted detergent and clean by hand for top cleaning. Never clean in a washing or drying machine. Let dry completely before storage.
5. Your canopy is designed as a temporary shelter and not to be used as a permanent structure.

OPTIONAL BACK WALL INSTRUCTIONS

1. Make sure the tent legs are fully extended. Attach the velcro of the back wall to the velcro inside of the canopy of your Prayer Station Tent.



2. Attach the velcro strips on the sides of the back wall around the Prayer Station Tent legs to secure the back wall.



Prayer Stations Inc. is not responsible for accidents as a result of use or misuse of the Prayer Station Tent. The Prayer Station Tent is designed to be used only as intended. Please do not use in a moving vehicle or in an area with strong winds over 25 MPH. We are not responsible for any accidents due to assembly errors. We are not responsible for the natural wear and tear of materials that inevitably occur with extended use or time. We are not responsible for defects caused by accidents, abuse, alteration, environmental damage, misuse or improper care.